INSTRUCTIONS TO CLEAN DISKS AND RE-ASSEMBLE T1 BUBBLE TAP

- Turn off water and open tap to release pressure
- Put plug in sink
- Turn tap lever and body anti-clockwise and unscrew handle and valve
- Remove washer on bottom of valve
- Remove ceramic disks and clean
- Replace disks and washer
- Screw valve into tap body, and tighten valve so the lever is in the upright position – DO NOT OVERTIGHTEN
- Turn on water, turn on tap to release air, turn tap off and check for leaks